

Quick Start Guide

4/8-Ch DVR

1. Install Hard Drive

Notice: 1. Support one SATA hard drive. Please use the hard drive the manufacturers recommend specially for security and safe field.

2. Please disconnect the power before being connected to other devices. Don't hot plug in/out

Step 1: Unscrew and Open the top cover, connect the power and data cables. Place the HDD onto the bottom case as below.



Fig 1-1 Connect HDD

Step 2: Screw the HDD as below.



Fig 1-2 Screw HDD

Notice: 1. For the convenience to install, please connect the power and data cables firstly, and then screw to fix.

2. Connections

2.1 Rear view for 4-ch DVR




Fig 2-1 Rear view for 4-ch DVR

1	4 CH Audio input	8	1-ch relay output. Connect to external alarm
2	Video input channels from 1-4	9	+5 V and Grounding

3	Audio output, connect to the sound box	10	Connect to external sensor1-4
4	Connect to monitor as an AUX output channel by channel. Only video display, no menu show	11	VGA output, connect to monitor
5	Connect to monitor	12	Network port
6	Connect to speed dome	13	Connect USB mouse or connect external USB devices
7	Connect to keyboard	14	POWER INPUT

2.2 Rear view for 8-ch DVR




Fig 2-2 Rear view for 8-ch DVR

1	4 CH Audio input	8	1-ch relay output. Connect to external alarm
2	Video input channels from 1-8	9	+5 V and Grounding
3	Audio output, connect to the sound box	10	Connect to external sensor1-8
4	Connect to monitor as an AUX output channel by channel. Only video display, no menu show	11	VGA output, connect to monitor
5	Connect to monitor	12	Network port
6	Connect to speed dome	13	Connect USB mouse or connect external USB devices
7	Connect to keyboard	14	POWER INPUT

3. Power on

Step1: connect with the source power; switch on the power button near the power port in the rear panel

Step2: the device will be loaded, and the power indicator will display blue

Step3: before start, a WIZZARD window will pop-up and show some information about time zone, time setup, network configuration, record configuration and disk management. User can setup here and refer to the concrete setup steps from the corresponding chapters. If users don't want to setup Wizard, please click Exit button to exit.

After the device power on, if there is no menu or only has live image display,

user can long press ESC/Exit button to switch.

Notice: this serial device can only display menu on VGA monitor or BNC monitor at one time, if there is live image display without menu display, please check up whether other device has menu display firstly, or long press ESC/Exit key to wait for login dialog box to appear. Long press ESC/Exit key can switch the output between BNC and VGA.

4. Basic setup

4.1 Accessing the DVR menus

4.1.1 Login

Press the MENU button which will bring the LOGIN dialogue box and enter the user name: admin and password: 123456



Fig 4-1 Login

4.1.2 Main menu setup

Click , or press ENTER button on the front panel can enter into the main menu. Menu→Setup refer to Fig 4-2



Fig 4-2 Main menu setup

Basic configuration: User can set video system, menu language, audio, time and authorization check.

Live configuration: Users can set name/time display, picture color and hide cameras.

Record configuration: Users can set record quality, frame rate, resolution, time stamp and recycle.

Schedule configuration: Users can set schedule for timer, motion detection,

and sensor alarm respectively.

Alarm configuration: users can set sensor type, alarm trigger and buzzer alarm.

Network configuration: Users enable network function, and configure IP address, DDNS, transmission video parameters here.

User configuration: Administrator can add, delete users, and change their authorization

PTZ configuration: Users can set protocol, baud rate, address, presets and auto cruise track here.

Reset configuration: Users can reboot the device.

4.2 DVR recording modes

Users need to install and format a HDD and set all the recording parameters before recording. There are four kinds of record modes.

4.2.1 Manual Recording

Users can press REC button on the front panel after quitting system setup. Press this button again to stop recording.

Or press REC button on remote controller and click again to stop.

Or click REC button on the tool bar with mouse and click again to stop.

4.2.2 Schedule Recording

Enter into main menu—schedule configuration (refer to Fig 4-3). Users can set different schedule time for every day in one week. If user wants a special schedule for one day can use Holiday function.

The column means the seven days of a week from Monday to Sunday and the row means 24 hours of a day. Click the grid to do relevant setup. Blue means checked area, gray means unchecked area.




Fig 4-3 Schedule record setup

4.2.3 Motion Detection Recording

Motion detection recording: when there is a motion event detected, the camera will be triggered to record and have an alarm out.

Enter into main menu-motion configuration (refer to Fig 4-4) and enable Detection first;



Fig 4-4 Motion detection interface

Enter Motion detection area (refer to Fig 4-5) to set Sensitivity and Detection area.



Fig 4-5 motion detection area setup

4.2.4 Sensor Alarm Recording

Enter into main menu-Alarm configuration (refer to Fig 4-6), enable Detection first and then setup the device type.



Fig 4-6 sensor alarm record

Enter into Trigger configuration and select alarm out, recording cameras and linked PTZ; set Alarm out hold time and Buzzer hold time. Click OK to save settings.

4.3 Playback

This unit supports live record playback, time search, event search and image search.

4.3.1 Live playback

Click Play  button to playback the record. Refer to Figure4-7. User can do concrete operation by click the buttons on screen.




Fig 4-7 live playback

4.3.2 Time search

Enter into Search configuration and select Time search. If it recorded in a certain day, the date will show highlight.

Select a date and press Search button. Click the time grid to set the play start time or input play record time manually. The selected time match the blue grid.

Click Play button. It will play from the time point where user set.

Click the relative buttons on the screen to do fast forward/rewind, pause, stop, and change the screen mode and re-search.




Fig 4-8 time search

4.3.3 Event search

Enter into Search configuration, select Event search (refer to Fig 4-9), and choose a certain day in the event search interface.

Click Search button to display the searched event information in the event list box. User can select date, channel and then tick off Motion, Sensor or All accordingly.

Double click a video file to playback.




Fig 4-9 Event search

4.3.4 Image search

In this interface, user can set start, end time and channels to search the captured images and save, lock or delete these images. There are at most 2000 images which can be saved in the SATA disk. If there are more images saved in the SATA disks than 2000 images, those additional images will supersede prior images. Double click the image with the left mouse to automatically playback from the time of the image captured.

4.4 Back up

This unit supports backup by USB Flash and USB HDD.

Enter into Backup interface (refer to Fig 3-10) and set the start & end time, select channels. Then click Search button. The searched data will be displayed in the data backup list box.

Press Backup button to begin to write video from HDD inside DVR to backup device. Click Apply button to start backup.



Fig 4-10 Backup setup

5. Remote Surveillance

In order to view the DVR from a network it must be connected to a LAN/WAN or internet. The network setup should be done accordingly.

5.1 Access DVR on LAN

- Please enter into Menu→Setup →Network Setup as shown in Fig 5.1.
- Input IP address, Subnet, Gateway. If using DHCP, please enable DHCP in both the DVR and the router. Enter into Menu → Information → Network, and user can check the network settings of the DVR.




Fig 5-1 Network configuration

- Enter into Record Setup to set network video parameters like resolution, frame rate etc.
- Open IE on a computer on the same network. Input the IP address of the

DVR in IE address bar and press enter. If HTTP port is not 80, add the port number after IP address or domain name.

- IE will download ActiveX component automatically. Enter the username and password in the subsequent window

Note: If the ActiveX cannot be downloaded or installed, please refer to Appendix A Q7 in the user manual.

5.2 Access DVR on WAN

1. Connect the DVR to internet through router or virtual server

- Please enter into Menu→Setup →Network Setup as shown in Fig 5-1.
- Input IP address, Subnet, Gateway. If using DHCP, please enable DHCP in both the DVR and the router.
- Forward IP address and port number in Virtual Server setup of the router or virtual server. Configure the firewall to allow accessing the DVR. (If the user has enabled the UPnP function in both the DVR and router, he can skip this step. Please refer to the relevant chapter for more details.)
- If users want to utilize dynamic domain name, please apply for a domain name in a DNS server supported by the DVR or router. Then add to the DVR or router.
- Open IE browser, input IP address, or dynamic domain name and enter. If HTTP port is not 80, add the port number after IP address or domain name.
- IE will download ActiveX automatically. Then a window pops up and asks for user name and password. Input name and password correctly, and enter to view.

2. Connect the DVR to Internet through dial-up ADSL

- Enter into the DVR's Main Menu→Setup→Network interface to enable PPPoE and then input user name and password received from your ISP. Next, click 'Apply'. The DVR will connect to the server and would give a confirmation message.
- When accessing the remote interface of DVR, user can input WAN IP to access directly (user can enter into Main menu→Information→Network interface to check IP address). The browser will download Active X control
- The following steps are the same as the connection way above.